

# MICROMAG


## **Operating Instructions (EN)**

#### **MODELS:**

17" DISK PAD ASSIST 20" DISK PAD ASSIST

17" DISK TRACTION 20" DISK TRACTION

20" EDGE TRACTION





Read these Instructions before using the machine.



Read these Safety Messages before using the machine.

#### INTRODUCTION

This manual is furnished with each new machine. This manual will allow the Operator to get the best performance out of your RPS manufactured Scrubber-Drier, Sweeper, Burnisher, or Orbital Scrubber. Read this manual thoroughly before operating or servicing the machine.

This machine will provide excellent performance, but the best results will be obtained at the most minimum costs if:

- The machine is regularly maintained per the machine Preventative Maintenance instructions provided.
- The machine is operated with reasonable care and caution.
- The machine is maintained with manufacturer supplied parts.

#### **ABOUT THIS MANUAL**

**TABLE OF CONTENTS:** Tells you where to look in the manual.

**SAFETY MESSAGES:** Section contains important information regarding hazard or unsafe practices of the machine. Levels of hazards are identified that could result in product or personal injury, or severe injury resulting in death.

**OPERATION CONTROLS / MACHINE COMPONENTS:** Shows you the different machine controls and features.

MACHINE SETUP: Tells you how to setup machine from un-crating to installing Squeegee and Brushes.

**MACHINE OPERATION:** Section is to familiarize the operator with the operation and function of the machine.

BATTERY CHARGING: Shows you how to charge the Batteries (on-board and off board charging).

**MAINTENANCE:** This section contains preventative maintenance to keep the machine and it's components in good working condition. They are listed in this general order:

- Batteries
- Scrub Brushes
- Adjusting Squeegee
- Service Schedule
- Machine Trouble Shooting


TROUBLE SHOOTING: A list of common problems that may occur.

MACHINE SPECS: Tells you Machine Specifications for the various parts of the machine.

**MACHINE INSTALL FORM:** Should be filled out upon machine installation and faxed to 1-866-632-6961 or on-line at **www.rpscorporation.com**.

**WARRANTY POLICY:** Tells you coverage, exclusions and limitations to Warranty.

NOTE: The Serial Number of your machine is located on the lower half of the Control Panel of the machine.



AS OUR POLICY IS ONE OF CONSTANT IMPROVEMENT - ALL INFORMATION AND SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.

- 2 -

# TABLE OF CONTENTS

Introduction2
About This Manual2
Table of Contents 3
Safety Messages 4
Safety Label Locations 6
Operation Controls7
Machine Components8
Machine Components 9
Machine Setup10
Un-Crating Machine:10Connecting Batteries:10Attaching Squeegee:10Adjusting Squeegee:11Removing Squeegee:11Replacing or Rotating Squeegee Blades:11Installing Disk Pad Driver or Brush:12Installing Driver Pads:12Replacing Driver Pads on Machine:12Installing EDGE Pads:13Adjusting Pad Assist Bias:13
Machine Operation       14         Pre-Cleaning Checklist:       14         Operating Hints:       14         One Pass Scrubbing (Pad Assist):       15         Scrub Only:       15         Vacuum Only:       15         One Pass Scrubbing (Traction):       16         Scrub Only:       16         Vacuum Only:       16         Adjust Solution Flow:       17         Draining Solution Tank:       17         Draining Recovery Tank:       17         Open Recovery Lid:       17         Flush Recovery Tank:       18         Clean "Drain Saver":       18

Clean vacuum Screen:	
Tip Tank:	
Squeegee Up:	
Squeegee Down:	
Vacuum Motor:	
Solution Filter:	
Cleaning Solution Filter:	20
Battery Charging	21
External Battery Charging:	21
On-Board Charger	22
On-Board Battery Charging (Optional):	
Battery Maintenance Guide	23
Safety:	
Inspection and Cleaning:	
Storage:	23
Maintenance	24
Daily Maintenance:	24
Weekly Maintenance:	24
Monthly Maintenance:	24
Yearly Maintenance:	
Storing Machine:	
Checking Battery Specific Gravity:	24
PM Records	25
Trouble-shooting	27
Machine Specs	29
Common Wear Parts	30
Round Disk Brushes:	30
Round Disk Pads:	
EDGE Pads and Screens:	
Squeegee Blade Kits & Assemblies:	
Soap Choices	
Machine Install / Warranty Registration	34
, ,	
Standard Warranty Policy	35

MICROMAG-OP-EN - 3 -

#### SAFETY MESSAGES

You will see four kinds of safety reminders in this manual:

# **ADANGER**

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

# **A** WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

# **ACAUTION**

CAUTION indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or damage to this machine or nearby objects. CAUTION also can be used to alert against unsafe practices.

# NOTICE

NOTICE indicates information considered important, but not hazard-related. This safety message may be related to property damage or warranty warnings.

Your safety, and that of others, is very important. Operating this machine safely is an important responsibility.

## DO NOT OPERATE THIS MACHINE UNLESS:

- You are trained and authorized to do so
- You have read and understood this Operator's Manual
- On surfaces with greater than a 2% grade unless this machine is equipped with a functional Parking Brake.

#### WHEN OPERATING THIS MACHINE:

- Remove loose objects from the floor that could be projected from the rotating Brushes
- Keep your hands and feet away from the rotating Brushes
- Do not operate this machine where flammable liquids are present
- Use caution when maneuvering

#### **BEFORE LEAVING THE MACHINE:**

- Park the machine on a level surface
- Turn the machine off

#### **BEFORE SERVICING THE MACHINE:**

Disconnect the Batteries

# **ADANGER**

Explosive hydrogen gas forms when Batteries are charging. An open flame or spark can cause this gas to explode. Serious personal injury or property damage could occur. Only charge the Batteries in this machine in a well ventilated area.

# **ADANGER**

Flammable materials can cause an explosion or fire. Do not use flammable materials in Tank or pick up.

- 4 - MicroMag-OP-EN

## **A** WARNING

The Batteries in this machine produce hazardous voltage which can cause electrical shock, burns and/ or electrocution. Always disconnect batteries before servicing this machine.

# **A** WARNING

When climbing or descending ramps, always drive machine forward. To avoid overturning the machine, Do not back down ramps. Do not drive across inclines. Do not turn while ascending or descending ramps. Overturning the machine can cause serious injury or death.

# **A** WARNING

Do not use water that exceeds 135°F / 57°C. If water is above said temperature, this will void the Tank Warranty.

# **A** WARNING

Do not park this machine on ramps or slopes. Always park this machine on a level, hard surface. Do not operate this machine outdoors or on uneven surfaces.

# **AWARNING**

The Batteries in this machine contain sulfuric acid, which causes burns to skin. If battery acid contacts clothing or skin, rinse the effected area with cold water immediately. If battery acid gets on your face or in your eyes, flush the area immediately with cold water and seek medical attention.

# **AWARNING**

To avoid electrical shock, do not operate this machine over electrical floor outlets.

# **ACAUTION**

To avoid damage to this machine, use only cleaning solutions and replacement parts recommended by the manufacturer.

# **ACAUTION**

Do not operate this machine if any parts have been damaged or removed.

# **A** WARNING

Dress safely. Do not wear rings or metal wrist watches when servicing this machine, as they can cause an electrical short circuit which can cause serious burns.

# **A** WARNING

Do not remove, paint over or destroy warning decals. If warning decals become damaged, call 1-262-681-3583 for free replacements.

# **A WARNING**

Dress safely. Do not wear a neck tie, scarf, or any loose or dangling clothing while operating this machine. Loose or dangling clothing or neck-wear can tangle in rotating parts, causing serious injury or death.

# **A WARNING**

Always turn off this machine before leaving it unattended. Do not allow untrained persons to operate this machine.

# **A** WARNING

NO RIDERS. Do not carry passengers on this machine. Do not use this machine as a stepladder or work platform.

# **A** WARNING

Understand the dynamic braking system before you operate the machine on ramps. Machine may coast.

# **A** WARNING

Before you service a Battery, always wear face protection, protective gloves and protective clothing. Battery acid or Battery explosion can cause serious injuries.

# **ACAUTION**

Always use the automatic battery charger provided by the manufacturer of this machine to charge the Batteries of this machine. It is designed to charge the Batteries at the appropriate rate. If you must use a different charger, disconnect the Batteries before charging to avoid damage to the electronic speed controller.

# **ACAUTION**


To avoid damage to the electronic control components of this machine, Do not store this machine outdoors. Do not pressure wash this machine.

MICROMAG-OP-EN - 5 -

#### **SAFETY LABEL LOCATIONS**


Read and obey all Safety Labels on your MicroMag Floor Scrubber. If you have questions about these labels, ask your supervisor.

These images indicate where on the MicroMag Safety Labels are located. If ever the labels become illegible, worn off, or torn, promptly report it to your supervisor and replace it.



- 6 - MicroMag-OP-EN


#### **OPERATION CONTROLS**




- 1. MAIN POWER SWITCH (OPTIONAL): Turns the machine ON and OFF
- 2. **KEY SWITCH:** Turns power on to the machine (Standard on Traction Drive, Optional on Pad Assist Drive)
- 3. SOLUTION CONTROL LEVEL: Controls solution flow (Up = LESS, Down = MORE)
- 4. VACUUM SWITCH: Turns the Squeegee Vacuum Motor ON and OFF
- 5. SQUEEGEE LIFT LEVER: Raises and lowers the Squeegee
- **6. BATTERY GAUGE / HOUR METER:** Indicates the amount of Battery charge remaining
- 7. SCRUBDECK DOWN PRESSURE GAUGE (OPTIONAL): Shows the amount of down pressure applied to Scrubdeck
- 8. SCRUBDECK SWITCH: Turns the Scrubdeck ON or OFF and UP or DOWN
- 9. SOLUTION FLOW SWITCH: Turns Solution Flow ON or OFF
- EMERGENCY SHUT OFF SWITCH (OPTIONAL): Shuts OFF the machine in case of emergency
- 11. HANDLE BAR: Adjustable Handlebar
- **12. ADJUSTABLE HANDLE BAR LOCK:** Pull out to adjust Handlebar and release to lock the Handlebar in place
- 13. REVERSE SWITCH: Pull back for reverse
- 14. DRIVE BUTTON: Press to drive forward, release to stop
- **15. SPEED CONTROL KNOB:** Controls the speed of the Traction Drive Turn counter-clockwise to reduce speed
- 16. CIRCUIT BREAKER: 25 AMP resettable circuit breaker for Vacuum Motor
- **17. CIRCUIT BREAKER:** 30 AMP resettable circuit breaker for Scrubdeck Motor (40 AMP for HD 1.2 HP motor option)
- 18. SPRAY JET [BLUE BOOT] (OPTIONAL): Activates Spray Pump for remote Spray Wand
- 19. RECHARGE CYCLE METER: Shows the amount of chargers on a machine
- **20. CHARGER PORT:** Red 50 used to receive charger input for optional external charger 24V ONLY!


MICROMAG-OP-EN - 7 -


#### **MACHINE COMPONENTS**






- 1. CASTER: Twin Casters for stability
- WALL ROLLERS: Helps protect machine when scrubbing near walls
- 3. MAINTIRES: Drive Tires
- 4. TRACTION DRIVE: Propels machine forward/reverse
- 5. SOLUTION FILTER: Filters water solution prior to scrubbing
- **6. SOLUTION FLOW SHUT OFF VALVE:** Meters solution rate (GPM)
- **7. SOLUTION FLOW VALVE:** Turns solution ON / OFF (Turns off when motor stops)
- **8.** "PAD ASSIST" DRIVE ADJUSTMENT KNOB: Adjusts amount of offset being applied to Brush
- 9. VACUUM MOTOR: Creates vacuum for Tank / Squeegee
- 10. "DRAIN SAVER" STRAINER: Helps prevent clogging of Drain Ports
- 11. VAC SCREEN: Protects Vacuum Motor from debris
- **12. RECOVERY LID:** Used for flushing out Recovery Tank area with fresh water





- 8 - MicroMag-OP-EN

#### MACHINE COMPONENTS



- 1. FRONT SOLUTION FILL POINT/LID: Front fill port for filling Solution Tank
- 2. FRAME CURTAIN: Helps control water from splashing.
- 3. TANK LATCH: Secures Tank to frame
- **4. SOLUTION SIGHT TUBE AND DRAIN HOSE:** Displays how much clean water is in the Tank and drains clean water
- **5. ADJUSTABLE SQUEEGEE HEIGHT WHEELS:** Height of wheels adjust to height of Squeegee
- **6. SQUEEGEE PITCH ADJUSTMENT:** Adjusts pitch of Squeegee Deflection should be even across entire blade
- 7. SQUEEGEE BLADE: Recovers dirty water from floor to be recovered by Vacuum Hose
- 8. SCRUBDECK FOOTPEDAL (OPTIONAL): Used to raise and lower the Scrubdeck
- **9. VACUUM HOSE:** Creates vacuum for Squeegee (NOTE: Keep free and clear of blockage)
- 10. REAR SOLUTION FILL POINT: Rear fill port for filling Solution Tank
- 11. RECOVERY DRAIN HOSE: Allows for controlled draining of Recovery Tank


MICROMAG-OP-EN -9 -

#### **MACHINE SETUP**

#### **UN-CRATING MACHINE:**

Carefully check the crate for any signs of damage and that the Batteries are in the unit.

To un-crate the machine, remove banding strips from around the crate. Take off the top and sides and dispose properly. Remove brackets *(A)* from machine wheels. Remove bolts *(B)* from pallet, then remove board *(C)*. Carefully roll the machine off of the base. Notify the carrier immediately if concealed damage is discovered.



#### **CONNECTING BATTERIES:**

Your machine is equipped with (2×) 12-Volt/ 85 AH, (2×) 12-Volt/ 130 AH, or (2×) 12-Volt/ 150 AH Wet Lead Acid, AGM, or Deep Cycle Batteries which form a 24 Volt system.

# (SEE PICTURE BELOW OR BATTERY DISCONNECT LABEL FOR CORRECT CABLE CONNECTIONS)


- Turn all switches to the OFF position and remove Key (if machine is equipped with Optional Key Switch).
- 2. Attach all Battery Cables as shown below.
- Turn ON main Key Switch and check the Battery Condition Meter to ensure correct installation. Charge Batteries if needed (SEE BATTERY CHARGING).

# **NOTICE**

Batteries are a possible environmental hazard. Consult your Battery supplier for safe disposal methods.

# **NOTICE**


Orientation of Batteries is critical for cables to reach.




**24 VOLTS** 

#### **ATTACHING SQUEEGEE:**


 Lower the Squeegee Mounting Plate by rotating the Squeegee Lift Lever (A) in a clockwise motion (SEE BELOW).



 Loosen the two knobs (B) on the Squeegee and slide them into the slots in the Squeegee Mounting Plate (SEE BELOW).



Tighten the two knobs and connect the Vacuum Hose (C) from the machine to the Squeegee (SEE BELOW).




 You may have to adjust the Squeegee Pitch (SEE ADJUSTING SQUEEGEE ON THE NEXT PAGE)


- 10 - MICROMAG-OP-EN

#### **ADJUSTING SQUEEGEE:**

 Turning Adjustment Knob (A) clockwise (tightening) will lower tips and raise the center of the Squeegee (SEE BELOW).




- Adjustable Wheel (B) (SEE ABOVE) has 3 holes. The
  closer to the machine the wheel is, the further from
  the ground the wheel becomes. The farther from the
  machine the wheel is, the closer to the ground the
  wheel becomes.
- This Squeegee is adjusted too far back and will not pick up on the corners (SEE BELOW). NOTE: Tips off of the floor.




4. This Squeegee is adjusted too far forward and will not pick up in the center (SEE BELOW).

NOTE: Center spaced off the floor.




This Squeegee is adjusted just right with good deflection across the entire rear Blade (SEE BELOW).



#### **REMOVING SQUEEGEE:**

- With the Squeegee in the up position, turn machine power off.
- 2. Disconnect Vacuum Hose (A) from Squeegee and loosen both knobs (B) (SEE BELOW).
- Pull Squeegee assembly backward from the lifting carrier.
- 4. Inspect or repair as needed and reinstall.



#### **REPLACING OR ROTATING SQUEEGEE BLADES:**


FOR SAFETY: Before leaving or servicing the machine, stop on a level surface, turn off machine and remove key.

- Remove the Squeegee Assembly from the machine.
   Remove Blade Retainer Strap and remove Squeegee Blade.
- 2. Rotate the Squeegee to new edge position or replace as required.
- 3. Install Blade on the locating pins of Squeegee Assembly.
- 4. Install Squeegee Retainer Strap.
- 5. Fasten and lock knobs, starting in the center and moving outwards.


MICROMAG-OP-EN - 11 -

#### **INSTALLING DISK PAD DRIVER OR BRUSH:**

- With empty Tanks, remove Squeegee and make sure the Tank latches (A) are locked on.
- Lower the Scrubdeck by depressing the Scrubdeck Switch (B) on the Handlebars and turn OFF the machine (for machines with manual foot-pedal Scrubdeck lifting - lower manually). Remove Key if Option equipped.
- Tip machine back by pulling back on Handlebar and allowing the machine to rest on the Triangle Squeegee Plate (C).




 Attach brushes or pads to motor drives. Squeeze the scissor locking device and lift brush up on to the Motor Drive Hub. Make sure the scissors close and lock on to the Brushes (SEE BELOW).



5. With Brushes locked into place, tip machine back down to a level surface.


#### **INSTALLING DRIVER PADS:**

- Select the correct Pads that best meet your cleaning application needs. Consult your local dealer for assistance.
- Pad Installation: Attach Pads to Pad Drivers before connecting Drivers to Motor Hub. Screw center clip (E) into place (SEE BELOW).



#### **REPLACING DRIVER PADS ON MACHINE:**

- Select the correct Pads or Brushes that best meet your cleaning application. Consult your local dealer for assistance.
- 2. With empty Tanks and Squeegee removed, tip machine back and rest on Triangle Plate.
- Attach Pads to Pad drivers and screw center clip (F) into place (SEE BELOW).




# **NOTICE**

NEVER place aggressive Pads (Maroon Prep, Dominator HD Strip, etc.) directly onto the Grip Face. Always use Red or Blue Spacer pad to prevent Grip Face damage.


- 12 - MICROMAG-OP-EN

#### **INSTALLING EDGE PADS:**

- 1. Turn off machine power (make sure that scrub deck is raised off of the ground). Remove Key if Option equipped.
- 2. With empty Tanks and Squeegee removed, tip machine back and rest on Triangle Plate.
- Select the correct Pads that best meet your cleaning application. Consult your local dealer for assistance.
- Remove any Pad previously attached to the EDGE Grip Face by pulling down from the corners (SEE BELOW).




5. Once Grip Face is clear of any Pads, place Pad wanted for application centered on the Grip Face (*This will leave a ½" overhang on all sides*) (**SEE BELOW**).




- 6. Press upwards on the Pad to secure it in place.
- With Pad attached securely to Grip Face of EDGE Deck, tip the machine back to standard sitting position and reattach Squeegee for machine to be ready to use.

#### **ADJUSTING PAD ASSIST BIAS:**


1. Release (2×) Tank latches (A) (SEE BELOW).



Tip Tank back (SEE BELOW).



 Turn the Pad Assist Adjustment wing nut (B) to the right to increase bias and to the left to decrease (SEE BELOW).



MICROMAG-OP-EN - 13 -

#### **MACHINE OPERATION**


#### **PRE-CLEANING CHECKLIST:**

Read and understand the Safety Messages section on Pages 3 and 4 before operating the machine.

- Check Battery Condition Gauge on the Control Panel. Make sure Batteries are fully charged before using.
- 2. Check the condition of the Pads or Brushes.
- 3. Check the condition of the Squeegee Blades.
- Raise the Scrubdeck and Squeegee before transporting then transport the machine to the filling station.
- 5. Turn the machine OFF.
- Fill the Tank with up to 10 gallons of clean water either at the front fill port (A) or rear fill port (B) (SEE BELOW).
- Add APPROVED cleaning chemical to the Tank.
   Use the proper dilution ratio indicated on the bottle.
   Contact us at 1(800)-634-4060 or +011-262-681-3583 if unsure.

## NOTICE

The clear tube (Solution Sight Tube) (C) at the rear of the machine indicates the amount of water in the tank (SEE BELOW).



# **▲ DANGER**

**EXPLOSION RISK!** Flammable materials can cause an explosion or fire. Do not use flammable materials in tank or pick up.

# **ACAUTION**

#### TO AVOID DAMAGE TO THIS MACHINE:

- Use approved detergents only
- Water temperature must not exceed 130°F/54°C
- · Do not use high-percentage bleach mixture

#### **OPERATING HINTS:**

- Observe the amount of solution the machine is dispensing on the floor and adjust to the desired flow. To increase the solution flow rate, pull the Solution Control Lever down. To shut the solution OFF completely, just release the Drive button, or use dash mounted switch.
- Keep an eye on the clear Vacuum Cover to make sure that there is not any foamy buildup in the Recovery Tank. If excess foam begins to develop, pour a recommended foam control solution into the Recovery Tank. Foam is usually an indication of excessive soap.
- Always operate at lower speeds when scrubbing around walls and objects. You should reduce the speed to maintain control when turning.
- 4. If squeegee starts to streak, raise and wipe the Blades with a clean cloth. If the problem continues, check the Squeegee Blades for wear or damage and rotate if needed. You may need to pre-sweep before scrubbing. (Only Use OEM Parts)
- 5. Change or turn over Pads when dirty.
- 6. Stay clear of objects protruding from the floor such as sockets, grates, etc, for they will damage the Pads and Squeegee Blades.
- Always keep an eye on your gauges. They let you know the status of a particular system at a glance. If your Battery Gauge is reading low you much stop immediately and recharge. Running the batteries dead will result in damage to the batteries.
- 8. When you run out of solution, raise the Scrubdeck and continue to vacuum the remaining water until it is all consumed. The Solution Sight Tube is used to indicate the level of detergent remaining in the Tank.
- 9. When you are ready to stop, raise the Scrubdeck, turn *OFF* the Solution Switch, raise the Squeegee and drive the machine back to the charging area. Be sure to drain both Tanks before storing the machine.

- 14 - MicroMag-OP-EN

#### **ONE PASS SCRUBBING (PAD ASSIST):**


- Turn on machine Power Switch (A) (if machine is equipped with Optional Key Switch), make sure the Speed Control Knob (B) is at a lower setting.
- Lower the Squeegee by rotating the Squeegee Lift Lever (C) all the way to the right. Turn on Vacuum Motor with Vacuum Switch on Control Panel (D).
- 3. Lower Scrubdeck head to the floor by pressing the Scrubdeck Switch on the Control Panel (E) (or by manually lowering the Scrubdeck with Foot Pedal option).
- Move the Solution Flow Lever (F) to regulate the amount of solution flow.
- 5. Begin scrubbing by pressing the Scrubdeck switch button *(F)* on the dash board or use *(optional)* green Drive Control Buttons. Adjust the Pad Assist adjustment knob *(B)* to the desired setting.
- Once the machine begins to move, check the Down Pressure Gauge (G) (Optional). Start scrubbing at the middle. Do not scrub in the red, or the Circuit Breaker will blow.
- 7. To operate the machine in reverse, simply pull the Reverse switch *(H)* back towards the Handlebar. The reverse speed is set to approximately 50% of the forward speed.
- 8. To stop the machine, shutoff Scrubdeck switch *(F)* and Vac Motor *(D)*.

#### **SCRUB ONLY:**

- Turn on machine Power Switch (A) while making sure the Speed Control Knob (B) is at a lower setting.
- Lower Scrubdeck head to the floor by pressing the Scrubdeck Switch on the Control Panel (E).
- 3. Move the Solution Control Lever *(F)* to regulate the amount of solution flow.
- 4. Begin scrubbing by pressing one of the green Drive Buttons *(G)* on the Handlebars. Adjust the Speed Control Knob *(B)* to the desired setting.
- To operate the machine in reverse, simply pull the Reverse Switch (H) back towards the Handlebar. The reverse speed is set to approximately 50% of the forward speed.
- 6. To stop the machine, let go of the Drive Buttons (G).

#### **VACUUM ONLY:**

- 1. Turn on machine Power Switch (A) while making sure the Speed Control Knob (B) is at a lower setting.
- Lower the Squeegee by rotating the Squeegee Lift Lever (C) all the way to the right. Turn on Vacuum Motor with Vacuum Switch on Control Panel (D).
- 3. Begin vacuuming by pressing one of the green Drive Buttons *(G)* on the Handlebars.



MICROMAG-OP-EN - 15 -

#### **ONE PASS SCRUBBING (TRACTION):**


- Turn on machine Power Switch (A), make sure the Speed Control Knob (B) is at a lower setting.
- Lower the Squeegee by rotating the Squeegee Lift Lever (C) all the way to the right. Turn on Vacuum Motor with Vacuum Switch on Control Panel (D).
- Lower Scrubdeck head to the floor by pressing the Scrubdeck Switch on the Control Panel (E).
- 4. Move the Solution Flow Lever **(F)** to regulate the amount of solution flow.
- 5. Begin scrubbing by pressing one of the green Drive Buttons *(G)* on the Handlebars. Adjust the speed control knob *(B)* to the desired setting.
- To operate the machine in reverse, simply pull the Reverse switch (H) back towards the Handlebar. The reverse speed is set to approximately 50% of the forward speed.
- 7. To stop the machine, let go of the Drive Buttons (G).

#### **SCRUB ONLY:**

- 1. Turn on machine Power Switch (A) while making sure the Speed Control Knob (B) is at a lower setting.
- Lower Scrubdeck head to the floor by pressing the Scrubdeck Switch on the Control Panel (E).
- 3. Move the Solution Control Lever *(F)* to regulate the amount of solution flow.
- Begin scrubbing by pressing one of the green Drive Buttons (G) on the Handlebars. Adjust the Speed Control Knob (B) to the desired setting.
- To operate the machine in reverse, simply pull the Reverse Switch (H) back towards the handle bar. The reverse speed is set to approximately 50% of the forward speed.
- 6. To stop the machine, let go of the Drive Buttons (G).

#### **VACUUM ONLY:**


- 1. Turn on machine Power Switch (A) while making sure the Speed Control Knob (B) is at a lower setting.
- 2. Lower the Squeegee by rotating the Squeegee Lift Lever *(C)* all the way to the right. Turn on Vacuum Motor with Vacuum Switch on Control Panel *(D)*.



- 16 - MICROMAG-OP-EN

#### **ADJUST SOLUTION FLOW:**

 Push down on the Solution Flow Lever (A) to increase the solution flow and push up on the lever to decrease solution flow (SEE BELOW).



#### **DRAINING SOLUTION TANK:**

To drain unwanted cleaning solution from the Solution Tank, perform the following steps:


#### (SEE BELOW)

 Pull the clear Sight Tube/Drain Hose (A) off barbed fitting.

# **NOTICE**


Get Supervisor APPROVAL first and drain at APPROVED locations only.

2. Rinse out Tank and Solution Flow system with clean water.



#### **DRAINING RECOVERY TANK:**

Always empty Recovery Tank when refilling the Solution Tank. You can refill the Solution Tank while the Recovery Tank is draining. To drain the Recovery Tank remove Drain Hose (B) from hook at rear of Tank and pop off cap (SEE BELOW). Rinse with fresh water.



# NOTICE

Leave Recovery Lid open while draining Tanks. Rinse thoroughly.

# **NOTICE**

Get Supervisor APPROVAL first and drain at APPROVED locations only.


#### **OPEN RECOVERY LID:**

1. Rotate Tank Lid **(B)** forward and full open to rest in a tipped open position **(SEE ABOVE)**.


MICROMAG-OP-EN - 17 -

#### **FLUSH RECOVERY TANK:**

- Rinse the Recovery Tank after every use (A). This will prevent heavy build-up on the bottom of the tank, foul odors as well as clogging of the drain hose (SEE BELOW).
- Remove Drain Hose (B) and open to allow for drainage of the Recovery Tank (SEE BELOW).



3. Flush Recovery Tank with water hose.



 After rinsing, reattach the Drain Hose (B) on hook (SEE ABOVE).


# NOTICE

Keep water off of Control Panel.

#### **CLEAN "DRAIN SAVER":**

With Recovery Lid open and Tank fully drained:


- Remove 2" Squeegee Intake Hose (A) from "Drain Saver" strainer (B) (SEE BELOW).
- 2. Remove stainless screen and dispose of debris.
- Rinse screen with fresh water from the outside while holding the screen upside down. This will allow for better cleaning.
- 4. Replace the screen into the bracket.
- 5. Replace 2" Squeegee Intake Hose.



#### **CLEAN VACUUM SCREEN:**

With Recovery Lid open and Tank fully drained:


- Remove Vacuum Screen retaining clip (C) (SEE BELOW).
- Pull Vacuum Screen and Float Ball Assembly (D) off of the Vacuum Box.
- 3. Rinse with hot water.
- 4. Dry thoroughly.
- 5. Replace the Vacuum Screen onto box.
- 6. Replace and tighten retaining clip.




- 18 - MICROMAG-OP-EN

#### **TIP TANK:**

- 1. Fully drain Solution Tank and the Recovery Tank.
- 2. Remove Squeegee or place in center.
- 3. Rotate Handlebar down 90° with the Handlebar Adjustment Knob (A). Unlatch Tank Latch (B) on each side of the machine (SEE BELOW).




 Tip Tank Back carefully until supported by strap as well as the Rubber Grommets on the Handlebar (SEE BELOW).




#### **SQUEEGEE UP:**

1. To raise the Squeegee off the floor, rotate Squeegee Lift Lever *(A)* counter-clockwise all the way to the left **(SEE BELOW)**.



#### **SQUEEGEE DOWN:**


 To Lower the Squeegee to the floor, rotate Squeegee Lift Lever (B) clockwise all the way to the right. To turn on Vacuum Motor use the Vacuum Switch (C) on the Control Panel (SEE BELOW).




MICROMAG-OP-EN - 19 -

#### **VACUUM MOTOR:**

- 1. The machine is equipped with a 24 volt, .75HP Vacuum Motor (A) (SEE BELOW).
- If foam or water gets past the Recovery Tank's Vac Screen/Ball system, adjust the bracket (B) in the Tank upwards (SEE BELOW).



3. The Vacuum Motor has an *(Optional)* "Foam Muffler" *(C)*, sound reduction walls *(D)* and vibration dampeners *(E)* that are available to quiet machine operation.





#### **SOLUTION FILTER:**

The solution system has an "Inline Filter" (A) to filter out cleaning solution prior to scrubbing (SEE BELOW).

#### **CLEANING SOLUTION FILTER:**

- To clean the Solution Filter, first close Solution Flow Valve by moving lever (B) upwards. Then unscrew the clear cap (C) from house (A) and remove the stainless steel screen (E) (SEE BELOW).
- 2. Rinse any debris from the screen with clean water.
- 3. Reinstall screen and screw cap back on tightly.
- 4. Re-open valve.





- 20 - MICROMAG-OP-EN

#### **BATTERY CHARGING**

#### **Charger Specifications**

- Output voltage of 24 Volts
- Output current of 12 amps max
- Input voltage of 110 Volts/ 60 Hz (220V/50 Hz available)
- Automatic shut off circuit
- Made for Deep Cycle Batteries

# **ADANGER**

Explosive hydrogen gas forms when Batteries are charging. An open flame or spark can cause this gas to explode. Serious personal injury or property damage could occur. Only charge the Batteries in this machine in a well ventilated area.

# **A** WARNING

Before you service a Battery, always wear face protection, protective gloves and protective clothing. Battery acid or battery explosion can cause serious injuries.

# **A** WARNING

The Batteries in this machine contain sulfuric acid, which causes burns to skin. If battery acid contacts clothing or skin, rinse the effected area with cold water immediately. If battery acid gets on your face or in your eyes, flush the area immediately with cold water and seek medical attention.


# **ACAUTION**


Always use the automatic battery charger provided by the manufacturer of this machine to charge the Batteries of this machine. It is designed to charge the Batteries at the appropriate rate. If you must use a different charger, disconnect the Batteries before charging to avoid damage to the electronic speed controller.


#### **EXTERNAL BATTERY CHARGING:**

- Transport machine to a well ventilated area for charging.
- 2. Turn the machine off. Tip back Tank.
- Check the water in each Battery (A). Do not charge
  the machine unless the water is slightly higher than
  the plates. If needed, add enough distilled water to
  just slightly cover the plates. Be careful not to over fill.
  Batteries can overflow during charging. Replace caps
  before charging.

- 4. First, plug the red 50 Charger plug into the machine's Charger Port (B). While the Charger plug is connected, plug the charger power cord into a grounded 110 Volt standard wall outlet (C).
- 5. The Charger will automatically begin charging and automatically shut off when fully charged *(check Battery gauge)*.
- 6. After the Charger has turned off First, unplug the Charger from the wall outlet. Second, unplug the red 50 Charger plug from the machine.
- 7. Recheck the cell level after charging. If needed, add distilled water up to the correct level. Be certain to replace the caps securely and to wipe off the top of the batteries with a clean cloth.







MICROMAG-OP-EN - 21 -

#### **ON-BOARD CHARGER**

#### **Charger Specifications**

- Output voltage of 24 Volts
- Output current of 12 amps max
- Input voltage of 110 Volts/ 60 Hz (220V/50 Hz available)
- Automatic shut off circuit
- Made for Deep Cycle Batteries

# **ADANGER**

Explosive hydrogen gas forms when Batteries are charging. An open flame or spark can cause this gas to explode. Serious personal injury or property damage could occur. Only charge the Batteries in this machine in a well ventilated area.

# **A** WARNING

Before you service a battery, always wear face protection, protective gloves and protective clothing. Battery acid or battery explosion can cause serious injuries.

# **A** WARNING

The batteries in this machine contain sulfuric acid, which causes burns to skin. If battery acid contacts clothing or skin, rinse the effected area with cold water immediately. If battery acid gets on your face or in your eyes, flush the area immediately with cold water and seek medical attention.


# **ACAUTION**


Always use the automatic battery charger provided by the manufacturer of this machine to charge the batteries of this machine. It is designed to charge the batteries at the appropriate rate. If you must use a different charger, disconnect the batteries before charging to avoid damage to the electronic speed controller.

#### **ON-BOARD BATTERY CHARGING (OPTIONAL):**

- Transport machine to a well ventilated area for charging.
- 2. Turn the machine off. Tip back tank.
- Check the water in each battery (A). Do not charge
  the machine unless the water is slightly higher than
  the plates. If needed, add enough distilled water to
  just slightly cover the plates. Be careful not to over fill.

- Batteries can overflow during charging. Replace caps before charging.
- 4. Plug the Charger power cord into a grounded standard wall outlet (*B*).
- 5. The green Indicator Light *(C)* will come on and the Charger will automatically begin charging. When finished, the Charger will automatically shut off as well as the green indicator light *(check Battery gauge)*.
- After the Charger has turned off, unplug the Charger from the wall outlet.
- Recheck the cell level after charging. If needed, add distilled water up to the correct level. Be certain to replace the caps securely and to wipe off the top of the Batteries with a clean cloth.





- 22 - MICROMAG-OP-EN

#### **BATTERY MAINTENANCE GUIDE**

#### **SAFETY:**

# **ADANGER**

Explosive hydrogen gas forms when Batteries are charging. An open flame or spark can cause this gas to explode. Serious personal injury or property damage could occur. Only charge the Batteries in this machine in a well ventilated area.

# **AWARNING**

Before you service a Battery, always wear face protection, protective gloves and protective clothing. Battery acid or battery explosion can cause serious injuries.

# **A WARNING**

The Batteries in this machine produce hazardous voltage which can cause electrical shock, burns and/or electrocution. Always disconnect Batteries before servicing this machine.

## **A** WARNING

The Batteries in this machine contain sulfuric acid, which causes burns to skin. If battery acid contacts clothing or skin, rinse the effected area with cold water immediately. If battery acid gets on your face or in your eyes, flush the area immediately with cold water and seek medical attention.

# **A** WARNING

Dress safely. Do not wear rings or metal wrist watches when servicing this machine, as they can cause an electrical short circuit which can cause serious burns.

#### **INSPECTION AND CLEANING:**

- · Keep Batteries clean and dry from residue
- Check that all vent caps are tight
- Use a solution of baking soda and water to clean if acid residue on Batteries or corrosion on the terminals
- Protective spray of petroleum jelly should be applied to terminals to reduce corrosion

#### **STORAGE:**


- Batteries should be fully charged prior to and during storage
- Never store discharged Batteries
- Store batteries in a cool, dry place but never below freezing - Recharge in storage a minimum of every 30

days

Recharge Batteries before putting them back into service

#### **WATERING:**

- Add water, NEVER ACID, to cells (distilled water recommended).
- Do not over water
- Before charging the Batteries, only add water if the plates are exposed. Add just enough water to cover the plates, then charge the Batteries. Once fully charged, add water to the proper level as indicated below.
- For full charge plus series Batteries add water to the maximum water level indicator (A).
- After watering, secure vent caps back on Batteries.



MICROMAG-OP-EN - 23 -


#### **MAINTENANCE**

#### **DAILY MAINTENANCE:**

- Remove the clean Pads or Brushes. Never use soiled Pads when cleaning. Replace Pads when they become packed with residue.
- 2. Remove and clean debris from the float shut-off screen and Drain Saver located inside the Recovery Tank.
- Drain and rinse Tanks thoroughly and flush out Solution Feed to deck.
- Inspect Vacuum Hose for any objects obstructing the air flow.
- Raise Squeegee and wipe Blades with a clean cloth.
   Store Squeegee in the raise position to prevent damage or setting of the Blades.
- 6. Wipe down machine if needed. Use a non-abrasive, non-solvent cleaner or a clean damp cloth.
- 7. Recharge the Batteries if needed.

#### **WEEKLY MAINTENANCE:**

1. Check Battery water level in each cell of the Batteries and fill as needed. Always use distilled water to refill Batteries. Batteries should be filled approximately ¾" to 1" above the plates. Overfilling will cause the batteries to leak during charging. The charging process creates gas bubbles inside the Battery, which effectively increases the volume of the electrolyte.



- 2. Clean Battery tops to prevent corrosion.
- 3. Flip Scrubdeck brushes / pads.
- Drain and rinse Tanks thoroughly. To thoroughly flush out any solution chemicals in solution line valves, refill Solution Tank with a few gallons of warm, clean water and run the machine until Tank is empty.

#### **MONTHLY MAINTENANCE:**

- 24 -

- Check Scrubdeck and Squeegee lifting cables for wear and spring tension.
- Check machine for water leaks and loose nuts and holts
- Check to see if battery cables are tightened. Tighten,

if needed, 8-10 ft/lb MAX.

4. Grease caster swivel and Squeegee pivot point.

#### **YEARLY MAINTENANCE:**

Call your local dealer for yearly maintenance.

#### **STORING MACHINE:**

- Be sure to flush the Tanks out completely. To thoroughly flush out any solution chemicals in solution line and valves, refill Solution Tank with a few gallons of warm clean water and run machine until Tank is empty.
- 2. Open the Recovery Tank lid to promote air circulation.
- 3. Raise Brush/Pad and Squeegee.

#### **CHECKING BATTERY SPECIFIC GRAVITY:**

Use a hydrometer to check the Battery specific gravity. Checking Gravity:

- Hydrometer
- Battery

## **NOTICE**

Do not take readings immediately after adding distilled water. If water and acid are not thoroughly mixed, the reading may not be accurate.

#### Check the hydrometer against this chart

SPECIFIC GRAVITY @ 80°F (27°C)	BATTERY CONDITION
1.265	100% Charged
1.225	75% Charged
1.190	50% Charged
1.155	25% Charged
1.120	Discharged

## **NOTICE**

If the readings are taken when the battery electrolyte is any temperature other than  $80^{\circ}F(27^{\circ}C)$ , the reading must be temperature corrected. To find the corrected specific gravity reading when the temperature of the battery electrolyte is other than  $80^{\circ}F(27^{\circ}C)$ : add (+) to the specific gravity reading 0.004 (4 points), for each  $10^{\circ}F(6^{\circ}C)$  above  $80^{\circ}F(27^{\circ}C)$ . Subtract (-) from the specific reading 0.004 (4 points), for each  $10^{\circ}F(6^{\circ}C)$  below  $80^{\circ}F(27^{\circ}C)$ .

## **PM RECORDS**

CUSTOMER INFORMATION									
CUSTOMER			EMA	IL					
ADDRESS						PHC	DNE		
CITY	STATE		ZIP	ZIP CONTACT					
MACHINE INFORMATION									
MODEL #:			SERI	AL #:					
WORK ORDER#:			HOU	R ME	ΓER:				
ISOLATOR HOUR METER:			RE-C	HARC	E COU	NTE	₹:		
BATTERY CONDITION		CELL 1	CEL	L 2	CELL	. 3	CELL 4	CELL 5	CELL 6
BATTERY 1 HYDROMETER									
BATTERY 1 WATER CONDIT	ION								
BATTERY 2 HYDROMETER									
BATTERY 2 WATER CONDIT	ION								
CLEAN BATTERY TOPS. CH	IECK BATTERY C	ABLE AND	TERMI	NAL C	ONDITI	ION.			
NOTES:									
PAD CONDITION									
SCRUB BRUSH FIBER LENG	GTH					ROT	ATED BRUS	SHES	
DISK PAD DRIVER				GOO	DD		WORN		EDS CEMENT
EDGE PAD GRIP FACE				GOO	OD		WORN		EDS CEMENT
CHECK OPERATION AND C	ONDITION OF:	IN S	SPEC	REF	PAIR F	PROB	LEM		

CHECK OPERATION AND CONDITION OF:	IN SPEC	REPAIR	PROBLEM
	IN SPEC	NEFAIN	PHOBLEIN
KEY SWITCH (OPTIONAL)			
BATTERY GAUGE			
BRUSH SWITCH ON / OFF			
REVERSE SWITCH (DRIVE ONLY)			
SOLUTION LEVER			
SOLUTION SOLENOID			
SCRUBDECK ACTUATOR			
BRUSH MOTOR			
VACUUM SWITCH			
VACUUM MOTOR PREFORMANCE			
SQUEEGEE LIFT SYSTEM			
SQUEEGEE ADJUSTMENT CABLE "HEIGHT"			
SQUEEGEE BLADES			
DRAIN HOSE AND PLUG			
SPRAY JET PUMP, HOSE & NOZZLE (OPTIONAL)			
BATTERY CHARGER CONNECTORS & FUNCTION			
PITCH OF SCRUB DECK (MUST BE LEVEL)			
PITCH OF EDGE DECK (MUST BE LEVEL)			

MICROMAG-OP-EN - 25 -

OLEAN AND LOD LUDDIOATE	1.0050	DEDAIR	DDOD! EM
	SPEC	REPAIR	PROBLEM
SOLUTION TANK CONDITION			
SQUEEGEE PIVOT POINTS & KNOBS			
SOLUTION FILTER CLEANING			
SCRUB DECK LINKAGE			
VISUALLY INSPECT IN	N SPEC	REPAIR	PROBLEM
DRAIN SAVER	VOI LO	TILITAIT	THOBLEM
VACUUM FLOATS & SCREENS			
VACUUM HOSES			
SOLUTION HOSES			
BLADE RETAINERS & HARDWARE			
SQUEEGEE WHEELS			
BRUSH SKIRTS			
CASTER CONDITION			
DRIVE WHEELS CONDITION			
COMMENTS			
SERVICING DISTRIBUTOR			
	5.4		
TECHNICIAN'S NAME	_ DATE		SIGNATURE
CUSTOMED'S NAME	DATE		SIGNATURE
CUSTOMER'S NAME	_ DAIE		SIGNATURE

- 26 - MICROMAG-OP-EN

# TROUBLE-SHOOTING

DROBI EM	CAUSE	SOLUTION
PROBLEM		SOLUTION CONTACT LOCAL CERVICING REALER
NO POWER - NOTHING OPERATES	FAULTY POWER SWITCH	CONTACT LOCAL SERVICING DEALER
	BATTERIES NEED CHARGING	SEE CHARGING BATTERY
	FAULTY BATTERY CARLE	REPLACE BATTERY
	LOOSE BATTERY CABLE	TIGHTEN LOOSE CABLE
	MAIN CIRCUIT BREAKER TRIPPED	WAIT 5 MINUTES FOR AUTO RESET DETERMINE CAUSE AND CORRECT
SCRUBMOTOR DOES NOT OPERATE	GREEN DRIVE BUTTON IS NOT DEPRESSED	DEPRESS BUTTON ON HANDLEBAR
	CIRCUIT BREAKER TRIPPED	RESET & REDUCE PRESSURE
	FAULTY SCRUBDECK MOTOR OR WIRES	CONTACT LOCAL SERVICING DEALER
VACUUM MOTOR DOES NOT OPERATE	FAULTY VACUUM SWITCH	REPLACE SWITCH
	CIRCUIT BREAKER TRIPPED	RESET & CHECK HOSE DETERMINE CAUSE AND CORRECT
	FAULTY VACUUM MOTOR	CONTACT LOCAL SERVICING DEALER
	CARBON BRUSHES WORN	CONTACT LOCAL SERVICING DEALER
INSUFFICIENT SOLUTION FLOW	SOLUTION TANK LOW	REFILL SOLUTION TANK
INGOLLIGIEM GOEGLIGIM FOW	FLOW LEVER TURNED DOWN	TURN LEVER MORE OPEN
	SOLUTION FILTER CLOGGED	REMOVE COVER AND CLEAN
	SOLUTION LINE CLOGGED	REMOVE AND BLOW OUT WITH COM- PRESSED AIR
	SOLUTION VALVE CLOGGED	REMOVE COVER AND CLEAN
NO SOLUTION FLOW	NO SOLUTION IN TANK	FILL SOLUTION TANK
NO SOLOTION LOW	SOLUTION SWITCH IS OFF	TURN SOLUTION SWITCH ON
	SOLUTION SCREEN CLOGGED	REMOVE AND CLEAN SCREEN
	FAULTY SOLUTION SOLENOID	CONTACT LOCAL SERVICING DEALER
	FAULTY SOLUTION SWITCH	CONTACT LOCAL SERVICING DEALER
	TAGELL SOCIOLOUS SWITCH	CONTACT ECOAL SERVICING BEALER
POOR WATER RECOVERY	RECOVERY TANK IS FULL	EMPTY RECOVERY TANK
	BALL / SCREEN IS CLOGGED	REMOVE SCREEN AND CLEAN
	VACUUM HOSE IS CLOGGED	REMOVE DEBRIS
	SQUEEGEE IS CLOGGED	REMOVE DEBRIS
	SQUEEGE BLADE IS WORN	ROTATE OR REPLACE BLADES
	FAULTY VACUUM HOSE	CONTACT LOCAL SERVICING DEALER
	VACUUM MOTOR GASKET TORN	CONTACT LOCAL SERVICING DEALER
	TANK GASKET FAULTY	CONTACT LOCAL SERVICING DEALER
	DRAIN PLUG LOOSE	TIGHTEN PLUG
	VACUUM MOTOR FAULTY	CONTACT LOCAL SERVICING DEALER
	BATTERY CHARGE LOW	CHARGE BATTERIES OVERNIGHT

MICROMAG-OP-EN - 27 -

PROBLEM	CAUSE	SOLUTION
POOR WATER RECOVER ON TURNS	WIPERS WORN	REPLACE WIPER MATERIAL
	WIPERS CHATTER	TIGHTEN PIVOT POINTS
	SQUEEGEE SWING IS BINDING	CONTACT LOCAL SERVICING DEALER
	INCORRECT SQUEEGEE SIZE	CONTACT LOCAL SERVICING DEALER
TIRES NOISY	BEARING DRY	GREASE BEARINGS
	FAULTY HUBS	CONTACT LOCAL SERVICING DEALER
POOR TRACTION	EXCESSIVE BRUSH PRESSURE	REDUCE PRESSURE WITH SWITCH
	WORN DRIVE TIRE	REPLACE TIRES
	HEAVY SOAP CONCENTRATION	CONTACT LOCAL SERVICING DEALER
SHORT RUN TIME	BATTERIES RUN DOWN	CHARGE BATTERIES TWICE
	BATTERIES STILL DOWN	CONTACT LOCAL SERVICING DEALER
	BATTERIES LOW ON WATER	FILL WITH DISTILLED WATER TO ¾" ABOVE THE LEAD PLATES
	BATTERIES OVER CYCLED	CONTACT LOCAL SERVICING DEALER

- 28 - MICROMAG-OP-EN

#### **MACHINE SPECS**

**BODY CONSTRUCTION/DIMENSIONS** TANK MATERIAL: CHASSIS CONSTRUCTION:

FRONT CASTERS: **REAR WHEELS:** 

SIZE  $(L \times W \times H)$ : SQUEEGEE SIZE:

WEIGHT (WITHOUT BATTERIES): WEIGHT (WITH BATTERIES):

**SCRUBDECK SYSTEM** 

**DISK BRUSH SIZE:** 

DISK SCRUBDECK MOTOR: **OPTIONAL SCRUBDECK MOTOR:** SCRUBDECK DOWN PRESSURE:

**EDGE PAD SIZE:** 

EDGE SCRUBDECK MOTOR:

SOLUTION SYSTEM

SOLUTION TANK CAPACITY: SOLUTION FLOW RATE: SOLUTION FILTER:

**RECOVERY SYSTEM** RECOVERY TANK CAPACITY:

VACUUM POWER: DRAIN HOSE:

VACUUM SPECS (LIFT / AIRFLOW):

**DEMISTING CHAMBER:** 

DRAIN SAVER:

**BATTERY SYSTEM** 

SYSTEM VOLTAGE:

STANDARD BATTERY AH RATING: OPTIONAL BATTERY AH RATING: BATTERY RUN TIME (STANDARD):

CHARGER (AUTOMATIC):

**DRIVE SYSTEM** 

STANDARD DRIVE: FORWARD SPEED:

**REVERSE SPEED:** 

**PRODUCTIVITY** 

SCRUBBING WIDTH: SCRUBBING RATE/HOUR (NORMAL): SCRUBBING RATE/HOUR (MAXIMUM): MICROMAG (PAD ASSIST)

POLY (5/16") (.79375 cm) 1/8" STEEL (.3175 cm)

(2×) 2.5"×1.38" [(2×) 6.35×3.5cm]  $(2\times)$  8"×2" [ $(2\times)$  20 × 5 cm]

35"×18"×38" (89×46×97 cm) 34"

115 LB. 298 LB. MICROMAG (TRACTION)

POLY (5/16") (.79375 cm) 1/8" STEEL (.3175 cm)

(2x) 2.5"x1.38" [(2x) 6.35x3.5cm]  $(2\times)$  8"×2" [ $(2\times)$  20 × 8 cm] 38"×18"×38" (89×46×97 cm)

34" 152 LB. 317 LB.

17-D: (1×) 17" (43cm) 17-D: (1x) 17" (43cm) 20-D: (1x) 20" (51cm) 20-D: (1x) 20" (51cm)

(1x) .75 hp (559 watts) / 200 RPM (1x) 1 hp (746 watts) / 200 RPM

0-125 LB (0-68 kg)

N/AN/A

(1x) .75 hp (559 watts) / 200 RPM (1x) 1 hp (746 watts) / 200 RPM

0-125 LB (0-68 kg) 20-EDGE: (1x) 20"x14"

20-EDGE: (1x) 1.2 hp (895 watts) /

2900 RPM

10 GAL (38 liters) 10 GAL (38 liters) 0 - 0.5 GPM (0 - 2 lpm) 0 - 0.5 GPM (0 - 2 lpm) STAINLESS / INLINE

STAINLESS / INLINE

10 GAL 0.75 HP

1.5" DIAMETER (4 cm) 70" / 70 cfm (178 cm / 21cmm)

1.25 GAL (5 liters) 30 in<sup>3</sup> (70 cm<sup>3</sup>)

10 GAL 0.75 HP

1.5" DIAMETER (4 cm) 70" / 70 cfm (178 cm / 21cmm)

1.25 GAL (5 liters) 30 in<sup>3</sup> (70 cm<sup>3</sup>)

24 Volts 24 Volts (2x) 85 Ah (2x) 85 Ah (2x) 130 Ah (2x) 130 Ah UP TO 3 HRS. UP TO 3 HRS. 8 AMP 8 AMP

PAD ASSIST 0.4 hp (298 watts), All Gear/ Sealed N/A

0-230 ft/min (4 mph) (6 kph) N/A0-130 ft/min (2 mph) (3 kph)

17", 20" 17", 20"

18,474 FT/HR 18,474 FT/HR 20,525 FT/HR 20,525 FT/HR

- 29 -MICROMAG-OP-EN

## **COMMON WEAR PARTS**

#### **ROUND DISK BRUSHES:**

BRUSHES	MODEL 17" DISK	MODEL 20" DISK
Super Grit	17-421SS	20-421SS
Tough Grit	17-421S	20-421S
Midi Grit	17-421C	20-421C
Light Grit	17-421PS	20-421PS
Poly (.028)	17-421P	20-421P
Nylon (.016)	17-421N	20-421N
Tampico	17-421T	20-421T
Pad Driver	17-421D	20-421D
<b>Diamond Driver</b>	17-421DD	20-421DD

#### **ROUND DISK PADS:**

# **NOTICE**

The ## in Disk Column Denotes Desk Pad Size: 17" or 20"

DISK PADS	DISK	LEVEL	COLOR
Super Black	##-422BB	Very High	Black
Black	##-422B	High	Black
Brown	##-422BR	High	Brown
Green	##-422G	Medium	Green
Blue	##-422BL	Moderate	Blue
Red	##-422R	Moderate	Red
White	##-422W	Light	White

## **EDGE PADS AND SCREENS:**

DESCRIPTION	20"×14" SCRUBDECK	13"×19"
White Pad	EDGE-4005	N/A
Red Pad	EDGE-4004	N/A
Blue Pad	EDGE-4003	N/A
Green Pad	EDGE-4002	N/A
Black Pad	EDGE-4001	N/A
White Driver Pad	EDGE-4025	EDGE-4019
60 Grit Sand Screen	EDGE-4026	EDGE-4020
80 Grit Sand Screen	EDGE-4027	EDGE-4021
100 Grit Sand Screen	EDGE-4028	EDGE-4022
120 Grit Sand Screen	EDGE-4029	EDGE-4023
150 Grit Sand Screen	EDGE-4030	EDGE-4024
20 Grit Sand Paper	EDGE-4031	N/A
36 Grit Sand Paper	EDGE-4032	N/A
60 Grit Sand Paper	EDGE-4033	N/A
80 Grit Sand Paper	EDGE-4034	N/A

- 30 -

EDGE-4035	N/A
EDGE-4012	N/A
EDGE-4013	N/A
EDGE-4014	N/A
EDGE-4015	N/A
EDGE-4016	N/A
EDGE-4070	N/A
EDGE-4018	N/A
EDGE-4036	N/A
N/A	EDGE-4011
EDGE-4006	N/A
EDGE-4007	N/A
EDGE-4008	N/A
EDGE-4017	N/A
300-4023	N/A
	EDGE-4012 EDGE-4013 EDGE-4014 EDGE-4015 EDGE-4016 EDGE-4070 EDGE-4036 N/A EDGE-4006 EDGE-4007 EDGE-4008 EDGE-4017

#### **SQUEEGEE BLADE KITS & ASSEMBLIES:**

SQUEEGEE SIZE	MODEL 17" DISK	MODEL 20" DISK	MODEL 20" EDGE	GUM RUBBER BLADE KIT	LINATEX BLADE KIT	COMPLETE SQUEEGEE ASSEMBLIES
26" Squeegee	Optional	Optional	Optional	130-770G	130-770L	130-7180
30" Squeegee	Optional	Optional	Optional	150-770G	150-770L	150-7180
34" Squeegee	Standard	Standard	Standard	180-770G	180-770L	180-7180

## **NOTICE**

Squeegee Blade kits include (1) Rear Blade, (1) Front Blade, and (2) Backup Wheels with hardware.

## **NOTICE**

Squeegee Assemblies (complete) listed above all come with Linatex Blades.

## **NOTICE**

Size is stamped into the top of the painted steel Squeegee body on all Squeegee's.

## **NOTICE**

The 26" Squeegee is designed for narrow aisles and may not have the same water control around tight turns as the large Squeegees.

MICROMAG-OP-EN - 31 -

## **SOAP CHOICES**



Industrial • Commercial • Environmentally Safe

## **TRADITIONAL DRUMS / TOTES**



## **DEMO / RENTAL QUARTS**



**WALL-MOUNTED SUPERCON** 



**ONBOARD AUTO DISPENSING** 



- 32 - MICROMAG-OP-EN

Onboard Availability	FORMULAS	
SUDS Approved	707 Citrus Green	An environmentally cleaner that works! It is a solvent free degreaser that works on oil, carbon, even rubber marks. Incorporates the latest technology in "Green Cleaning".
SUDS Approved	733 Low pH	Safe on most surfaces not harmed by water alone. Low scale formula to prevent alkali buildup in cleaning equipment, while offer detergent to emulsify oil.
SUDS Approved	755 High Power	Ideal solvent fortified degreaser. This butyl based detergent is penetrating, fast acting, and deep cleaning with built-in corrosion inhibitors. It is our most effective degreaser.
SUDS Approved	757 Gloss	A high gloss detergent designed to dry to a bright shine. It is ideal for use on finished surfaces, tile, epoxy, or enamel. The special formula removes salt residue, scuff marks and dirt, while leaving no residue behind. The result is a clean, non-slip surface, ready for immediate use.
SUDS Approved	797 HD	The Heavy Duty concentrate is a Super alkaline detergent, formulated for heavy soil, grease, and thick buildup. Popular in machine shops, auto and truck repair, and other facilities with oil, hydraulic fluids and cutting oils.
**Below Sold in bul	k concentrate only. No	nt available as a SuperCon, PowerDose or SUDS product
	727 Pretreat**	Designed to quickly remove tire marks, oil stains and buildup that has accumulated. This pretreat uses the powerful cleaning of natural citrus extract and is intended to be used directly on the floor at 100% concentrate.
	744 Tough Stuff**	Ideal for applications with Hard Water problems. It is safe to use in pressure washers and automatic scrubbers. The formulation enhances soil suspension, digests oil and grease, while supporting extra water conditioner.
		Distributed by:
PowerCat P.O. Box 503 Racine, WI 53 Phone: 414-74		

MICROMAG-OP-EN - 33 -

MACHIN	NE INSTALL / WARRANTY	REGISTRATION			
Installing Dealer:	Installed By:				
Location: (City, State):	Install Date:  End-User Contact:				
End-User Company Name:					
Address:	City/State:	Zip:			
Phone:					
Model:					
BUYER'S REPRESENTATIVE HAS RECEIVED	INSTRUCTION IN PROPER OPERATION	ON OF THE FOLLOWING CONTROLS AND FEATURES:			
emptied.  - Shroud and pad/brush removal and ir - Side Wiper and Curtain adjustment at - Solution valve and filter operation (rer - LCD display operation, 4 hour meters - Tank tilt back feature, only when both - Squeegee hose removal and checking	nstallation nd maintenance for water control moval and cleaning) s (key switch, brush, traction drive, vacuu tanks are fully drained				
SWEEPERS  - Demonstrate proper removal and rep - Method for cleaning the dust filter, en - Correct operation of the main broom	rating range to avoid tripping the circuit be placement of main broom and side broom mptying out the debris hopper and correct and side broom levers, and understands door and not to operate through standing	ns ot installation s to park with brushes in UP position			
EDGE MACHINES  - EDGE scrubbers must have their iso - Customer understands the Grip Face		250 hours of use. improper use or direct contact with the floor.			
- Parking brake override - Charging operation and customer un - Seat and steering wheel adjustment - Customer has read and understands - Battery and Machine Maintenance G - Manufacturer's website is a good sou	aderstands batteries have limited "cycles" the list of WARNINGS/CAUTIONS in the builde posters hung up and reviewed urce of information (Videos, PM Sheets) adelivered, reviewed, understood, and con	e Operator manual			
Installed By (print)		Signature			
Buyers Representative (print)		Signature			

Buyer agrees to pay for any repairs, adjustments, or secondary training that manufacturer determines is excluded from the warranty.

Complete and Fax form to 1-866-632-6961 or Online at www.rpscorporation.com

- 34 - MICROMAG-OP-EN

#### STANDARD WARRANTY POLICY

RPS Corporation warrants its machines, parts and accessories to be free of manufacturer's defects for the periods specified below. Warranty will be granted at the sole discretion of RPS Corporation and is subject to final claim and parts review by R.P.S. Corporation and its vendors. This policy is effective January 1, 2013 and is subject to change on production units at a future date.

#### **COVERAGE, EXCLUSIONS AND LIMITATIONS:**

**Coverage:** All Models sold (Except Floor Machines: 1 Year Parts / 6 Months Labor / No Travel)

Parts: 36 months / 1,500 hours on "Power On" hour meter

**Labor:** 12 months

**Travel:** 3 months (150 mile maximum)

Poly Tanks: 7 Years (Water must not exceed 135°F/57°C) / 3,000 Hours

**OEM Parts:** 90 Day New Part Warranty

**Validity:** Fully completed Machine Delivery Form (online or fax) is on record at RPS and machine is serviced by Factory Authorized Personnel.

**Limitation:** Warranty will begin on date of machine installation to end-user or 6 months after shipment from RPS Corp. to the distributor if unsold at that time.

This warranty includes all parts on the machine except normal wear parts. Some of these exceptions are:

- EDGE / ORBITZ isolators (250 hours on average)
- Squeegee Blades, Wiper Blades, Skirts and Curtains.
- Caster Wheels, Squeegee Wheels and Bumpers.
- Lights (Strobe, Headlights, or Bulbs).
- · Chains and Belts.
- Filters, Screens, and Vacuum Bags.
- Motor Brushes and commutater wear.
- Brooms, Brushes, Pads and Pad Retainers.
- Hoses and Tubing.
- Drive Tires, Pneumatic Wheels and Tubes.
- Rubber Floor Seals and Gaskets.
- Vacuum motors with evidence of moisture or debris intrusion or > 400 hours.
- The Batteries (see below).
- **NOT COVERED:** Routine maintenance, adjustments or parts damaged from abuse, neglect, improper use of the machine, or lack of scheduled "daily, weekly, monthly" maintenance in accordance with our published PM Sheets.

**POLY TANKS:** 7 Years Coverage against leakage due to manufacturer's defect in materials or workmanship. Tank warranty void if water used exceeds 135°F/57°C

**NOTE:** Freight coverage for 3 Years under the parts section of warranty.

**BATTERIES:** Warranted through battery manufacturer for **One (1) Year** (pro-rated) from the date of delivery. The battery manufacturer approves or denies the warranty coverage after analysis. We rely on solely on their review.

**NOTE NOT COVERED:** Damage from lack of water, failure to use OEM charger, or non-distilled water. Battery terminals – Battery terminals and cable connections are covered for 30 days from the shipment of the machine. (Battery terminals tightness should be inspected every 30 days.)

MICROMAG-OP-EN - 35 -



1711 South Street
Racine, WI 53404
www.rpscorporation.com
www.factorycat.com
www.tomcatequip.com
Tel. US: 800-634-4060

Tel. Int: (011) 262-681-3583

Fax: 866-901-3335